

Код F3071

WASCHTISCHBATTERIE XS

- n. 2 Flexschläuche
- Push-open Ablaufgarnitur 1"1/4


Finishes



ИЗОБРАЖЕНИЕ



Общие условия продажи в нашем действующем прайс-листе.



This drawing is the property of FIMA Carlo Frattini. Any complete or partial reproduction, or any transmission to third party without FIMA Carlo Frattini authorization is forbidden.